

High Vacuum

HVU Control panel

Geovent HVU control panel is used to control the Geovent HVU devices.

The control panel is available in 2 versions:

- STD is with automatic filter cleaner and automatic start / stop.
- FRQ has a built-in frequency inverter for demand control, with automatic start / stop and automatic filter cleaning.



HVU Control panel

Ordering table

Art. No.	Description
19-133	Control panel for HVU with direct start
19-131	Control panel for HVU with soft-starter
19-121	Control panel for HVU 7,5 kW FRQ
19-122	Control panel for HVU 11 kW FRQ
19-123	Control panel for HVU 15 kW FRQ
19-124	Control panel for HVU 18,5 kW FRQ
19-125	Control panel for HVU 22 kW FRQ